

## Variable Of TECHSAS NetCDF Files For Water Velocity Meter

**file \*-hullsoundspeed-PP\_SVPCN\_008.hss (directory ARCHIV\_NETCDF/ hullsoundspeed)**

VARIABLE	OBSERVATION
sndspeed	water sound speed derived from measures
temp	temperature of water
time	acquisition time