

Variable Of TECHSAS NetCDF Files For Thermometer

file *-intake-PP_SBE*_007.ths (directory ARCHIV_NETCDF/intake)

VARIABLE	OBSERVATION
intaketemp	temperature of water measured at the intake
time	acquisition time